1 Before driving		1-5.	Opening and closing the windows and moon roof	
			Power windows 86	
1-1.	Hybrid system		Moon roof89	
	Hybrid system 24			
	Hybrid system precautions 27	1-6.	Refueling	
	Energy monitor/consumption		Opening the fuel tank cap 92	
	screen32			
	Hybrid vehicle driving tips 37	1-7.	Theft deterrent system	
			Immobilizer system 96	
1-2.	Key information		Alarm98	
	Keys 39		Theft prevention labels	
			(for U.S.A.)100	
1-3.	Opening, closing and locking			
	the doors	1-8.	Safety information	
	Smart access system with		Correct driving posture 10	
	push-button start44		SRS airbags 103	
	Wireless remote control54		Front passenger occupant	
	Doors 57		classification system115	
	Trunk60		Child restraint systems 120	
			Installing child restraints 124	
1-4.	Adjustable components (seats,			
	mirrors, steering wheel)	2	When driving	
	Front seats			
	Driving position memory	2 1	Deixinananaaduusa	
	(driver's seat)	Z-1.	Driving procedures	
	Head restraints		Driving the vehicle	
	Seat belts		Power (ignition) switch	
	Steering wheel		EV drive mode	
	Inside rear view mirror		Hybrid transmission	
	Outside rear view mirrors 83		Turn signal lever159	
			Parking brako 160	

	Horn161	2-5. Drivin	g information
		Cargo	and luggage240
2-2.	Instrument cluster	Vehic	le load limits 243
	Gauges and meters 162	Winte	r driving tips 244
	Indicators and warning	Trailer	towing 247
	lights 165	Dingh	y towing 248
	Multi-information display 169		
	Head-up display 175	3 Interio	or features
2-3.	Operating the lights and		
	windshield wipers	3-1. Using	the air conditioning system
	Headlight switch183	and o	defogger
	Automatic High Beam188	Auton	natic air conditioning
	Fog light switch 194	syste	m 252
	Windshield wipers and		vindow defogger
	washer		:h260
	Headlight cleaner switch 200	Winds	shield wiper de-icer 261
2-4.	Using other driving systems	3-2. Using	the audio system
	Cruise control 201	Audio	system262
	Dynamic radar cruise	Using	the radio 265
	control	Using	the CD player 273
	LKA (Lane-Keeping Assist) 217	Playin	g MP3 and WMA
	Driving assist systems		281
	Hill-start assist control		ating an iPod [®]
	Pre-Collision System 232		er
		-	ating a USB memory er296
		Optim	nal use of the audio
			m304
		Using	the AUX adapter 307
			the steering wheel switches

3-3.	Using the Bluetooth $^{\circledR}$ audio	3-6.	Using the storage features	
	system		List of storage features	
	Bluetooth® audio system 311		• Glove box	
	Using the Bluetooth® audio		Console box	
	system 314		• Cup holders	
	Operating a Bluetooth®		Bottle holders	
	enabled portable player 319		Auxiliary boxes	3/0
	Setting up a Bluetooth® enabled portable player 322	3-7.	Other interior features	
	Bluetooth [®] audio system		Sun visors	371
	setup 327		Vanity mirrors	372
			Clock	373
3-4.	Using the hands-free phone		Power outlets	374
	system (for cellular phones)		Seat heaters and	
	Hands-free system for		ventilators	375
	cellular phones		Armrest	377
	Using the hands-free system		Rear sunshade	378
	(for cellular phones) 332		Floor mat	380
	Making a phone call		Trunk compartment	
	Setting a cellular phone 345		features	381
	Security and system setup 350		Garage door opener	383
	Using the phone book		Compass	391
			Safety Connect	395
3-5.	Using the interior lights			
	Interior lights list	4	Maintenance and care	
	• Personal lights			
		4-1.	Maintenance and care	
			Cleaning and protecting the vehicle exterior	402
			Cleaning and protecting the vehicle interior	406

4-Z.	1*laintenance
	Maintenance requirements 409
	General maintenance
	Emission inspection and maintenance (I/M)
	programs 415
4-3.	Do-it-yourself maintenance
	Do-it-yourself service
	precautions416
	Hood
	Positioning a floor jack 420
	Engine compartment 422
	12-volt battery 433
	Tires 437
	Tire inflation pressure 445
	Wheels448
	Air conditioning filter 450
	Electronic key battery453
	Checking and replacing fuses455
	Headlight aim (LED headlights)

Light bulbs......469

	Emergency flashers	482
	If your vehicle needs to be towed	483
	If you think something is wrong	489
	Event data recorder	490
5-2.	Steps to take in an emergen	су
	If a warning light turns on or a warning buzzer sounds	492
	If a warning message is displayed	501
	If you have a flat tire	521
	If the hybrid system will not start	530
	If you lose your keys	532
	If the electronic key does not operate properly	533
	If the vehicle 12-volt battery is discharged	536
	If your vehicle overheats	541
	If the vehicle becomes stuck	545

When trouble arises

5-1. Essential information

6	Vehicle specifications	
6-1.	. Specifications	
	Maintenance data (fuel, oil level, etc.)	548
	Fuel information	
	Tire information	
6-2	2. Customization	
	Customizable features	572
6-3	3. Initialization	
	Items to initialize	584
7	For owners	
	Reporting safety defects for U.S. owners	586
	Seat belt instructions for Canadian owners (in French)	587
	Index	
Abl	breviation list	590
Alp	habetical index	592
Wh	nat to do if	604